


# OPERATING INSTRUCTIONS

## MODEL RVL-20 TC

### PRESSURE RELIEF VALVE



#### APPLICATIONS:

Valve should only be used for clean, or filtered gases or fluids that do not crystallize or solidify. When liquids or gases contain solid matter, which might cause internal clogging or improper operation of the valve, a strainer with a fine wire mesh should be installed before the inlet of the valve. In-line strainer fittings or basket strainers can be purchased from STRA-VAL to solve this problem.

#### PRINCIPLE OF OPERATION

This is a diaphragm and spring type relief valve where the spring constantly opposes the pressure acting against the diaphragm, which seals of the inlet port from the outlet port at the valve seat. The desired set pressure or relief is achieved by compressing the spring until the spring force is adequate to balance the pressure force acting against the diaphragm. When the inlet pressure exceeds the set pressure, the diaphragm will open to relieve the excess pressure. The valve is generally used for low-pressure sanitary relief service where good accuracy is required. The large diaphragm in proportion to the seat results in a large change in force unbalance with very low-pressure changes.

The valve can operate in any orientation, vertical, horizontal, etc. When the valve is oriented with the outlet connection facing down, the valve becomes self draining.

#### MAINTENANCE & REPAIR

The valve should be periodically checked for proper operation. Reducing the spring compression from its current pressure setting can easily do this. Eventually the diaphragm should open and begin to discharge liquid or gas under pressure. **Make sure that the discharge is properly piped to a safe area in order avoid any personal injury**

The valve is relatively maintenance free, and the only part that would require attention is the diaphragm and the valve seat the diaphragm is usually the only part requiring replacement and should be replaced immediately if found to be ruptured, or leaking which would be evident with leakage visible from the spring chamber above the clamp. Therefore, a replacement should be kept on hand for replacement convenience.

The valve seat is the other area to examine, in case there is extreme corrosion or wear which would reduce the sealing ability against the diaphragm. If the damage is not too severe, the valve seat can be remachined and restored to produce an "as new" surface, thereby avoiding the need to purchase an entire new valve.

#### PROCEDURE FOR DISASSEMBLY

Make sure the valve is isolated and is not under pressure. Next remove the valve from the system. Back out the spring adjusting screw until there is no longer any spring compression. It may also be removed completely if desired. Unscrew the spring chamber

MATERIAL LIST & SPECIFICATION		
1	ADJUSTING SCREW	304
2	LOCK NUT	304
3	SPRING CHAMBER	316L
4	SPRING PUSHER	304
5	SPRING	302SS/17-7PHSS
6	DIAPHRAGM NUT	304
7	LOCK WASHER	304
8	UPPER DISC	304
9	V BAND CLAMP ASS'Y	300#
10	DIAPHRAGM	VITON/TFE
11	SCREW, DIAPHRAGM	316
12	BODY	316L
* 300 SERIES STAINLESS STEEL		

Dimensions				
Size	A	B	C	D
1-1/2	3	5.25	2.13	12
2	3	5.25	2.13	12.5

MAX SPRING RANGE 8-80 PSI  
MIN SPRING RANGE 2-22 PSI

PH 973-340-9955 FX 973-340-9933 21 COLLINGS AVE. GARFIELD, N.J. 07030	<b>STRA VALVES</b> <b>STRAINERS VAL</b>
MAT. St. Stl NONE	TYPE Sanitary Relief Valve Diaphragm Type With TC (TriClamp Connections)
DATE 10/26/2000 DWG EDC	DWG NO RVL20-TC

# **STRA** VALVES STRAINERS **VAL**

# **OPERATING INSTRUCTIONS MODEL RVL-20 TC PRESSURE RELIEF VALVE**

using the flats provided on top of the spring chamber. Now the diaphragm is exposed. Remove the diaphragm, usually an electrometric diaphragm, Buna, Viton, EPDM, or PTFE (Teflon). Check to see if there are any tears, cuts or severe signs of wear or abrasion, particularly, in the seat area where it contacts the valve body. Replace if in doubt.

Next, examine the seat, which is a raised section immediately surrounding the outlet port. Check to see that there are no obvious wear marks or any signs of erosion or corrosion. The seat can be remachined or polished smooth in a lathe if required or sent to a valve repair facility.

Don't forget to examine the adjusting spring to look for signs of corrosion or outright failure. Replace if necessary. Springs are usually always in stock at STRA-VAL and can be shipped readily.

## **REASSEMBLY & TEST**

When all the valve parts are cleaned and inspected, the valve can be reassembled in reverse order. Also, make sure no foreign particles such as gasket materials are embedded in the valve seat, which might cause the valve seat to stay partially open and cause unwanted leakage.

When the spring and spring hardware is assembled and the spring chamber clamped to the body tightly, the valve is ready for final installation and test. Testing should be done with the valve completely piped up with the discharged piped safely away. At the proper system over pressure, turn the adjusting screw until the valve begins to open. Next reduce the system pressure to the normal operating pressure and check to see if the valve reseats properly and shuts off.

If it is not possible to change the system pressure to an overpressure condition, at which point the valve must open, then the valve must be tested and set off line using a hydrostatic testing device.