



OPERATING INSTRUCTIONS

MODEL RVC-05-P

PLASTIC RELIEF VALVE

Another reason for replacing or repairing a valve is if there is excessive leakage from the valve seat. If this happens even with the spring compressed to the maximum (this should only be temporarily done for test purposes), this is an indication the poppet and or valve seat on the body is worn, damaged, or a particle lodged in the seat causing the valve to constantly leak. If leakage is observed through the spring chamber weep hole or through the spring adjusting screw, this indicates there is leakage in the piston seal which requires replacement. This would be visible only while the valve is discharging and there is some pressure on the outlet side of the valve.

APPLICATIONS:

This all plastic relief valve can be used for corrosive, non-adhesive or abrasive fluids, where the materials selected are compatible with the fluid and will not cause buildup, and crystallization which could cause sticking or keep the poppet from opening. When liquids contain debris or other solid matter, which also might cause internal clogging or improper operation of the valve, a strainer should be installed before the inlet of the valve. Basket strainers or filters can be purchased from STRAVAL to solve this problem.


Any problematic fluids that may cause the valve to work improperly should be frequently flushed.

PRINCIPLE OF OPERATION:

This is a poppet and spring type back pressure reducing or bypass valve where the spring constantly opposes the pressure acting against the poppet which seals off the inlet port from the outlet port at the valve seat. The desired set pressure is achieved by compressing the spring until the spring force is adequate to balance the pressure force acting against the poppet. When the inlet pressure exceeds the set pressure, the poppet will open to relieve the excess pressure. This series will operate in applications where back pressure is present or where the valve discharges directly to atmosphere. The piston is balanced and unaffected by downstream pressure.

MAINTENANCE & REPAIR

The valve should be periodically checked for proper operation. This can be easily done by reducing the spring compression from its current pressure setting. Eventually the poppet should open and begin to discharge liquid. **Make sure that the discharge is properly piped to a safe area in order to avoid any personal injury.** If the poppet fails to open with the adjusting screw sufficiently backed out and the valve is under pressure, the poppet is probably frozen in place. If this condition exists, the valve must be **immediately removed from service** and replaced or repaired.





OPERATING INSTRUCTIONS

MODEL RVC-05-P

PLASTIC RELIEF VALVE

PROCEDURE FOR DISASSEMBLY

Make sure the valve is isolated and is not under pressure. Next remove the valve from the system. Back out the spring adjusting screw until there is no longer any spring compression. It may also be removed completely if desired. Unscrew the spring chamber using a strap wrench on top of the spring chamber.

Now the top of the poppet is exposed. While still assembled, test to see if the poppet is free to move by hand. There should only be a slight resistance to movement resulting from the O-ring friction between the piston and the body. The piston can now be pulled out through the top of the body. Examine the O-ring or seal to see if any deterioration has taken place and replace if necessary. Next examine the poppet seating surface where it contacts the body and the mating surface on the body. Usually if there is severe leakage, the condition of these seating surfaces will indicate a cause upon inspection.

Examine the body bore where the piston or poppet is housed. If the surface is not smooth, the bore should be wiped with the appropriate solvent or cleanser. The same should be done with the piston or poppet outside diameter. If the valve body and poppet require re-machining from extreme wear or corrosion, use only an experienced tool room machinist to perform this operation on a precision lathe, as the parts must be completely concentric to within .001 TIR. If this is not done properly, the valve will not seat properly.

If the bore requires re-machining, there is a risk that too much clearance will result in the seat not closing properly. Consult factory for proper clearances of your specific valve. If the valve is severely damaged and if it is not practical to re-machine because side clearances would be excessive, then a new valve should be purchased, or the valve shipped to STRAVAL for a repair evaluation and possible repair or replacement.

Don't forget to examine the adjusting spring to look for signs of corrosion or outright failure. Replace if necessary. Springs are normally in stock at STRAVAL and can be readily shipped.

REASSEMBLY & TEST

When all the valve parts are cleaned and inspected, the valve can be reassembled in reverse order.

Make sure a valve seal lubricant is used to lubricate the seal and is compatible with the ELASTOMER used.

Make sure no dirt or foreign particles are embedded in the valve seat, which might cause the valve seat to stay partially open and cause unwanted leakage.

When the spring and spring hardware is assembled and the spring chamber threaded on to the body tightly, the valve is ready for final installation and test.

Testing should be done with the valve completely piped up with the discharged piped safely away. At the proper system over pressure, turn the adjusting screw until the valve begins to open. Next reduce the system pressure to the normal operating pressure and check to see if the valve reseats properly and shuts off.

If it is not possible to change the system pressure to an over-pressure condition, at which point the valve must open, then the valve must be tested and set off line using a hydrostatic testing device.